

# F.S.T. Company

---

## **Connect a FST Timer 4 Wire Model to a FST Wall Switch with a RJ11 Connector.**

In the Tanning Room install a RJ11 Telephone Surface Jack as follows:

<i>Wires From Timer</i>	<i>Terminals on Surface Jack</i>
Red	Red
White	Yellow
Green	Green
Black	Black

Then connect a phone cord from the Surface Jack to the Wall Switch installed in your bed.

## **Connect a FST Timer 3 Wire Model to a FST Wall Switch with a RJ11 Connector.**

In the Tanning Room install a RJ11 Telephone Surface Jack as follows:

<i>Wires From Timer</i>	<i>Terminals on Surface Jack</i>
Red	Red
White	Yellow
Black	Green and Black

Then connect a phone cord from the Surface Jack to the Wall Switch installed in your bed.

These instructions also work in reverse....